





**OPEN THE QR CODE READER** OR YOUR CAMERA ON YOUR PHONE TO SCAN.

Protect your purchase with a FREE Extended 1 year Warranty + Save a big 20% **OFF** on your next purchase with Teabloom.

**IMPORTANT:** Must register within 14 days from the date of your coupon code now at: TEABLOOM.COM/WELCOME

CUSTOMER CARE:

### CARE INSTRUCTIONS

Your All-Beverage Travel Tumbler is designed for a long and happy life.

Your flask will last for a long time providing you are aware that...

Do not fill to the top as this may cause leaks (leave about 2 cm gap).

Gently twist the lid on securely. Over-twisting can break the lid.

To prevent leakage, make sure the threads are aligned and the silicone seal is securely positioned in the lid.

Do not microwave or freeze.

Do not use with carbonated beverages.

Do not use fine ground coffee, it may clog the filter.

To avoid buildup from possible fermentation, do not leave dairy or citrus beverages in the product for more than 12 hours.

Hand washing is recommended as dishwasher may damage silicone seal.

Please visit Teabloom.com for more information, videos and delicious beverage recipes.

FIND RECIPES AT TEABLOOM.COM











T E A B L O O M®

**BREW TUMBLER** TRAVEL FLASK

TEA · COFFEE · FRUIT WATER













# FOR YOU, **FOR THF** FARTH.

Teabloom takes on the take-away cup culture with the beautiful. versatile All-Beverage Travel Tumbler, BPA-free. Earth-friendly. Doing good never looked so good.

#### **USING THE ALL-BEVERAGE TRAVEL TUMBLER WITH 2-WAY INFUSER/FILTER**

Enjoy your favorite beverage everywhere you go. The All-Beverage Flask's stainless steel infuser has innovative smaller holes to brew perfect hot or cold tea, cold-brew coffee, and fruit-infused water. Hot stays hot, cold stays cold, and you stay happy.

FOR HOT TEA: Remove infuser. unscrew the 2 components, place fresh tea leaves or tea bag in infuser basket, lock components back together, and place back in flask. Add hot water and steep to taste (3-5 minutes).

#### FOR COLD-BREW COFFEE OR TEA:

Remove infuser, unscrew the 2 components, place coarse-ground coffee or fresh tea leaves in infuser basket, lock components back together, and place back in flask. Fill flask with fresh water. Refrigerate for 12-24 hours for coffee or 6-12 hours for tea.

FOR FRUIT-INFUSED WATER: Remove infuser, unscrew the bottom component, add desired fresh fruits and water in flask, place short filter component back in flask. Allow to infuse.



## Thank you tor your order

Because we want you to love your purchase, we've taken great care to package it carefully.

#### **IMPORTANT:**

Your new Teabloom product is 100% guaranteed. In the unlikely event of breakage or other problems, please contact us as soon as possible so we can resolve the issue. Just email us at customerlove@teabloom.com and include your order number if you have it. We promise to respond quickly.







